

Fiber Termination Box 24Ports(FS-24A)

1. Product picture



2. Description

This 24ports FS-24A fiber termination box is in accordance with the industry standard requirements of YD/T2150-2010. It's mainly used in FTTX access network system. The box is made of high strength PC plastic alloy injection molding, which has good sealing and aging resistance. It integrates fiber splicing, splitting, distribution, storage and cable connection in box.

3. Features

- PC+ABS material ensures strong and light body
- Water-proof, dust-proof, anti-aging
- Easy installations: Ready for wall mounted, installation kits provided
- Space saving: Double-layer design for easier installation and maintenances
- Integrated with splice cassette and cable management rods
- Manage fibers in a reasonable fiber radius condition



- Water-proof design with IP-65 Protection level

4. Application

- CATV, LAN, WAN network
- FTTX Systems
- Telecommunication network
- Used for wall-mounted or pole-mounted application

5. Specification

Product Name	Fiber Termination Box 24Ports(FS-24A)
Model Number	FS-24A
Ports	24
Available Cable	Outdoor or Indoor Cable
Outlet	24Small Ports + 2 Cable Ports
Installation way	Wall mounting or pole mounting
Material	PC or ABS
Color	Grey/White
Size	315(H)*270(W)*105(D)mm
Weight	1.2 kg
Suitable adapters	SC/LC Adapters
IP Grade	IP65
Working Temperature	-40℃~+80℃
The atmospheric pressure	70KPa~108KPa


6.Product configuration list

● Product name	Models	Quantity	Remark
● Box	FS-24A	1pc	
● Fiber heat shrinkable	Φ1.5×60mm	24pcs	
● Nylon cable ties	3×100mm	6pcs	
● Expans	M8×40mm	4pcs	
● Key		1pc	

7.Packing

7.1 Product package: Each pcs of box packed by Bubble bag,and put in the inner box.

7.2 Carton packing (MM)

	Packing measurement (MM)	590*350*585
	Quality(PCS/Carton)	10pcs
	Gross weight (KG/Carton) Net weight (KG/Carton)	15.5KG 14KG